



# AccuValve Bluetooth® Configuration Option



The AccuValve 6000 and 4000 series are available with a Bluetooth® configuration option, which alleviates the requirement for a USB cable connection when accessing the airflow valve via Accutrol's free, intuitive Insight software.



The AccuValve line of critical airflow control valves incorporate a simple and intuitive graphical user interface which enables the user to configure the valve for their specific requirements. Accutrol's Insight software is provided free of charge and insures that the owner is not required to contact the manufacturer when changes are required in the field.


The AccuValves come standard with the ability to connect to the valves using a USB C connector. Optional Bluetooth configuration can be added, which alleviates the requirement for a USB connector allowing much easier connection options when valves are mounted in hard to reach spaces.

## Bluetooth® Specifications

The 6000 and 4000 Series AccuValve is ordered with an optional Bluetooth module that provides wireless connectivity between the AccuValve and configuration PC equipped with Bluetooth version 4.2 or 5.0.

Minimum Requirements for PC or Tablet

- Windows 10 Operating System
- Bluetooth Version 4.2 or 5.0
- AccuValve Insight Software Version 8.2 or later



The AccuValve wireless option incorporates a Bluetooth Low Energy Module (BLE) with an external antenna to maximize the range. The BLE Module transmits the AccuValve Tag Name as the Bluetooth identifier in the advertising packet to ensure the user selects the correct device to connect to. The only means for communicating to the AccuValve via Bluetooth is by using the AccuValve Insight configuration software, which uses a proprietary communications protocol to prevent other devices from communicating with the AccuValve.